

US UK Dear user Thank you for you choosing REDRAGON Brand, to protect your rights and for better customer service, we ask that you note our warranty rules. 1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included. 2. Consumable parts (such as foot stick) and spare parts replacement are not included in our warranty. 1	OS support Windows XP/Vista/Win7/Win8/Win10/Win11 Product Feature Ergonomic design N-Keys rollover Double injection for durable keycaps High-performance gaming switches Backlighting Modes FN+INS, switch 3 backlighting modes: 1. The trial of Light; 2. Breathing; 3. Normally on FN+HOME, switch 3 backlighting modes: 1. Ripple Graff; 2. Pass without Trace; 3. Coastal FN+PGUP, switch 3 backlighting modes: 1. Hurricane; 2. Accumulate; 3.Digital Times FN+DEL, switch 3 backlighting modes: 1. Go with the stream; 2. Clouds fly; 3. Winding Paths FN+END, switch 3 backlighting modes: 1. Flowers blooming; 2.Snow winter jasmine; 3.Swift action FN+PGDN, switch 3 backlighting modes: 1. Both ways; 2.Surmount; 3. Fast and the furious Keyboard function FN+WIN, Lock Windows and APP function, repeat to unlock. FN+“ ” 4 Level running speed adjustable FN+“←” Adjust the backlight running direction FN+“→” Adjust the backlighting color, colors switching by circle 2	FN+“↑”“↓” 4 Level brightness adjustable FN+PRTSC To restore default as flow mode Install the software CD in packaging or download the software from www.redragonzone.com for Macro recording and backlight setting Multi-media keys FN+F1= Open the media player FN+F2= Volume down FN+F3= Volume up FN+F4= Mute FN+F5= Stop FN+F6= Pre-track FN+F7= Play/ Pause FN+F8= Next track FN+F9= E-mail FN+F10= Home FN+F11= Calculator FN+F12= Search FAQ 1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer. 2. If you spill liquid on the keyboard, please remove keyboardsUSB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again. 3	FCC Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. 4
PT Prezado usuário, Obrigado por escolher a marca REDRAGON . Para proteger seus direitos e oferecer um melhor atendimento ao cliente, pedimos que você observe as regras da nossa garantia. 1. Dentro do período da garantia, os reparos são garantidos nos casos de falha devido a problemas no circuito elétrico. Danos causados pela desmontagem, por impactos violentos, imersão em água, ligação em correntes ou voltagens incorretas e danos causados por desastres naturais, como incêndios, inundações ou terremotos, não estão incluídos. 2. Peças que sofrem desgaste (como pés) e a substituição de peças avulsas não estão incluídas em nossa garantia. 5	Compatibilidade com OS Windows XP/Vista/Win 7/Win 8/Win 10/Win11 Recursos do produto Design ergonômico N de teclas rollover Injeção dupla para teclas mais duráveis Teclas para jogos de alto desempenho Modos de iluminação de fundo FN+INS, alterna entre três modos de iluminação de fundo: 1. O teste da luz 2. Respiração 3. Normalmente ligado FN+HOME, alterna entre três modos de iluminação de fundo: 1. Gráfico de ondas 2. Passagem sem pistas 3. Costeira FN+PGUP, alterna entre três modos de iluminação de fundo: 1. Furacão 2. Acumulado 3. Horários digitais FN+DEL, alterna entre três modos de iluminação de fundo: 1. Segue o fluxo 2. Nuvens voadoras 3. Caminhos tortuosos FN+END, alterna entre três modos de iluminação de fundo: 1. Flores surgindo 2. Jasmim de inverno 3.Ação rápida FN+PGDN, alterna entre três modos de iluminação de fundo: 1. Ambos os lados 2.Vencedor 3. Velozes e furiosos Funções do teclado FN+WIN, Bloqueia o Windows e aplicativo, repita para desbloquear. FN+“ ” 4 Ajuste de velocidade de 4 níveis FN+“←” Ajusta a direção do movimento da iluminação de fundo FN+“→” Ajusta a cor da iluminação de fundo, cores alternando em círculos FN+“↑”“↓” 4 Nível de brilho ajustável FN+PRTSC Para restaurar o modo de fluxo padrão 6	Instale o software do CD que acompanha a embalagem ou baixe o software de www.redragonzone.com para gravação de macros e configuração da iluminação de fundo Teclas multimídia FN+F1= Reprodutor de mídia FN+F2= V- FN+F3= V+ FN+F4= Mudo FN+F5= Parar FN+F6= Faixa anterior FN+F7= Reproduzir/pausar FN+F8= Próxima faixa FN+F9= Email FN+F10= Principal FN+F11= Calculadora FN+F12= Pesquisas Dúvidas frequentes 1. Se o teclado não responder, verifique se o cabo USB do teclado está inserido corretamente na porta USB correspondente, ou experimente outra porta USB no computador. 2. Se ocorrer o derramamento de líquido sobre o teclado, remova imediatamente o cabo USB que liga o teclado ao computador. Seque o excesso de líquido e deixe o teclado em um local aquecido (por exemplo, sob uma lâmpada) para deixar que seque 7	 REDRAGON DEVARAJAS MECHANICAL GAMING KEYBOARD  Please scan here to download user manual Wired Mechanical Gaming Keyboard Operating Instructions

型号	K556RGB/8856		备注： 尺寸：100x100mm (风琴折页) 材质：80g书写纸 印刷：单黑色双面印刷				Easton Tech 	
名称	说明书							
日期	2024-10-18							
页码	1 OF 1		文件编号					
绘图	雷国建	审核			核准		版本	A.1