

US UK

Dear user

Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.


1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.

2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.


O.S. Support

Windows XP/ Vista/ Win 7/ Win 8/ Win 10/Win 11/Mac O.S.

How to connect the keyboard with multi-ple devices



1



Wired Connection

1. [2.4G/OFF/BT] switch on "2.4G".
2. Connect the keyboard to the computer with USB cable.
3. The computer will recognize and configure the keyboard automatically.

2

2.4G Wireless Connection

1. [2.4G/OFF/BT] switch on "2.4G", the LED indicator flashes in Green, plug the USB receiver into your computer USB port, the keyboard will connect with computer automatically.
2. If auto-connection unsuccessfully, or you want to connect to new device, plug out the USB

3

receiver, press and hold [FN]+[R] for 3 seconds, the LED indicator quickly flashes in Green, plug the USB receiver into computer USB port, after paired the LED will turn to steady on.

BT Connection

1. [2.4G/OFF/BT] switch on "BT".
2. Press and hold [FN]+[Q/W/E] for 3 seconds, LED indicator flashes in Blue[1] or Cyan[2] or Pink[3] quickly.
3. Turn on BT function and search for available device, it will find "BT3.0 KB and BT5.0 KB" device names. Select a BT name to pair, after paired the LED will turn to steady on.
4. To switch the BT connections between BT1/BT2/BT3, press [FN]+ [Q/W/E].

Product Features

Backlight

1. The default: 16 backlight patterns switch by pressing [FN] + [, <] to cyclic switch the light patterns.
2. Press [FN] + [N] to cyclic adjust backlight brightness, total 5 levels.
3. Press [FN] + [M] to cyclic adjust light rotating speed, total 5 levels.
3. Backlight color switching (available on limited light patterns): [FN] + [, >] to cycling switch Red, Green, Blue, Yellow, Purple, Cyan, White, RGB.
4. Backlight DIY: Press [FN] + [Back space] to enter DIY mode, press [FN] + [Back space] again to start recording, "CAPS" LED will flashing till the recording completed, Continuously press the key to select the color you want to set, once key light color setting are completed, press [FN] + [Back space] to save.

[WIN] lock

Press [FN] + [WIN] to lock [WIN] key, repeat to unlock (DO NOT lock the key when using on MAC O.S.)

Windows / MAC shortcut keys switching

Use MAC/WIN switch on the left side of keyboard.

4

Commands of key combinations with [FN] key

[1~+=]+[F1~F12] swift: key [1~+=] output [1 ~5~+] by default, double click [FN] to swift keys value to key [F1~F12], [FN] light on White, repeat to recovery.

FN+P: Insert	FN+L: Delete
FN+[[: Home	FN+;: End
FN+]]: Page up	FN+/: Page down
WINDOWS O.S.	
FN+F1: Screen brightness -	F1: Screen brightness -/ FN+F1=F1
FN+F2: Screen brightness +	F2: Screen brightness +/ FN+F2=F2
FN+F3: Multiple windows	F3: Multiple task / FN+F3=F3
FN+F4: Speech recognition (O.S. win10 or newer)	F4: Siri / FN+F4=F4
FN+F5: Show desktop	F5: Show desktop / FN+F5=F5
FN+F6: Search	F6: Search / FN+F6=F6
FN+F7: Pre track	F7: Pre track / FN+F7=F7
FN+F8: Play/Pause	F8: Play/Pause / FN+F8=F8
FN+F9: Next track	F9: Next track / FN+F9=F9
FN+F10: Mute	F10: Mute / FN+F10=F10
FN+F11: Volume -	F11: Volume down / FN+F11=F11
FN+F12: Volume +	F12: Volume up / FN+F12=F12

5

Restore factory settings

Press and hold [FN] + [Tab] for 3 seconds.

Power save mode & How to recharge

On wireless/BT connection mode, when keyboard without any operation over 3 minutes, the keyboard backlight will turn off to save the battery, when keyboard without any operation over 30 minutes, the keyboard will enter power save mode, press any key to wake up.

When battery is low, the backlight will turn off, the power LED will blink red slowly when pressed a key.

Connect the keyboard with computer for charging, the power LED will steady on Red when charging, after fully charged turn to steady on Green.

Battery power indicator: Press and hold [FN] + [] to show the battery level, [1-0] keys will light on to indicating battery level, release to back to current backlight mode.

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.



6

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.

DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.

DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.

DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.

DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.

DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.



This device contains licence-exempt transmitter(s) (receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

7

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

8

PL

Drogi Użytkowniku

Dziękujemy za wybranie marki REDRAGON. Aby chronić swoje prawa i korzystać z lepszej obsługi klienta, zwróć uwagę na nasze warunki gwarancji.


1. W okresie gwarancji naprawa jest objęta gwarancją w przypadku awarii spowodowanej problemami z obwodami elektrycznymi. Nie uwzględnia się szkód spowodowanych przez człowieka, takich jak demontaż, silne uderzenia, zanurzenie w wodzie, podłączenie do niewłaściwego prądu lub napięcia ani szkód spowodowanych przez błęski żywiołowe, takie jak pożar, powódź lub trzęsienie ziemi.

2. Części eksploatacyjne (np. stopka) oraz części zamiennie nie są objęte naszą gwarancją.

Obsługiwane systemy operacyjne:

Windows XP/Vista/7/8/10/11, MacOS

Jak połączyć klawiaturę z wieloma urządzeniami



9

Połączenie przewodowe:

1. Ustaw przełącznik [2.4G/OFF/BT] na „OFF”.
2. Podłącz klawiaturę do komputera za pomocą kabla USB.
3. Komputer automatycznie wykryje i skonfiguruje klawiaturę.

Połączenie bezprzewodowe 2.4G:

1. Ustaw przełącznik [2.4G/OFF/BT] na „2.4G”. Dioda LED zacznie migać na zielono. Podłącz odbiornik USB do portu USB w komputerze—klawiatura automatycznie się połączy.
2. Jeśli połączenie nie powiedzie się lub chcesz połączyć się z nowym urządzeniem: Wyjmij odbiornik USB, naciśnij i przytrzymaj [FN]+[R] przez 3 sekundy. Dioda LED zacznie szybko migać na zielono. Włóż odbiornik USB do portu komputera – po sparowaniu dioda przestanie migać.

Połączenie BT

1. Ustaw przełącznik [2.4G/OFF/BT] na „BT”.
2. Naciśnij i przytrzymaj [FN]+[Q/W/E] przez 3 sekundy – dioda LED zacznie szybko migać: • Q – niebieski (BT1) • W – cyjan (BT2) • E – różowy (BT3)
3. Włącz BT w urządzeniu i wyszukaj dostępne urządzenia. Pojawi się „BT3.0 KB” lub „BT5.0 KB” – wybierz jedną z nazw, aby sparować. Po sparowaniu dioda przestanie migać.
4. Przełączanie między BT1/BT2/BT3: naciśnij [FN]+[Q/W/E].

Funkcje produktu

Podświetlenie:

1. 16 domyślnych wzorów – cykliczna zmiana trybów: [FN] + [, <].
2. Szybkość animacji: [FN] + [N] (Dostępnych jest 5 prędkości).
- Jasność podświetlenia: [FN] + [M] (Dostępnych jest 5 poziomów).

10

3. Zmiana koloru (w wybranych wzorach): [FN] + [, >] (Cykliczna zmiana między Czerwony, Zielony, Niebieski, Żółty, Fioletowy, Cyjan, Białe, RGB).
4. Tryb własny (DIY): • [FN] + [Backspace] – wejście do trybu DIY • ponownie [FN] + [Backspace] – rozpoczęcie nagrywania (dioda CAPS miga) • wybierz kolory dla poszczególnych klawiszy • ponownie [FN] + [Backspace] – zapis ustawień

Blockada klawisza [WIN]:

[FN] + [WIN] – blokuje klawisz [WIN]; ponowne naciśnięcie odblokowuje (Nie używać na Mac OS!)

Przełączanie skrótów Windows/Mac:

Przełącznik MAC/WIN po lewej stronie klawiatury.

Kombinacje klawiszy z [FN]

Przełączanie między [1~+=] i [F1~F12]: Domyślnie [1~+=] – kliknij dwukrotnie [FN], aby przełączyć na [F1~F12] (dioda FN świeci na biało). Ponowne kliknięcie – powrót do domyślnych wartości.

Skróty:

FN+P: insert	FN+L: Delete
FN+[[: Home	FN+;: End
FN+]]: Page up	FN+/: Page down

11

Funkcje Windows	Funkcje Mac OS
FN+F1: Jasność ekranu –	F1: Jasność ekranu –
FN+F2: Jasność ekranu +	F2: Jasność ekranu +
FN+F3: Widok wielu okien / zadań	F3: Widok wielu okien / zadań
FN+F4: Rozpoznawanie mowy (Win10+)	F4: Siri
FN+F5: Pokaż pulpit	F5: Pokaż pulpit
FN+F6: Szukaj	F6: Szukaj
FN+F7: Poprzedni utwór	F7: Poprzedni utwór
FN+F8: Odtwarzaj/Pauza	F8: Odtwarzaj/Pauza
FN+F9: Następny utwór	F9: Następny utwór
FN+F10: Wyciszenie	F10: Wyciszenie
FN+F11: Głośność –	F11: Głośność –
FN+F12: Głośność +	F12: Głośność +

Przywracanie ustawień fabrycznych

Przytrzymaj [FN] + [ESC] przez 3 sekundy.

Tryb oszczędzania energii i ładowanie

- W trybie bezprzewodowym/BT:
- brak aktywności przez 3 min – wyłączenie podświetlenia
 - brak aktywności przez 30 min – tryb oszczędzania energii
 - naciśnij dowolny klawisz, by wznowić pracę

12

Niski poziom baterii:

- podświetlenie się wyłączy
- dioda zasilania miga na czerwono po naciśnięciu klawisza

Ładowanie:

- podłącz do komputera – dioda zasilania świeci się na czerwono
- po pełnym naładowaniu zmienia kolor na zielony

Poziom baterii:

Naciśnij i przytrzymaj [FN] + [] – podświetli się klawisze [1~0], pokazując poziom naładowania.

Ostrzeżenie: Prąd ładowania: 5V = 2A maks. Wbudowany akumulator litowo-jonowy 1 szt.

FAQ – Najczęstsze pytania

1. Klawiatura nie działa? Upewnij się, że kabel USB jest poprawnie podłączony. Spróbuj użyć innego portu USB.
2. Złamanie klawiatury? Odłącz natychmiast kabel USB, wytrzyj nadmiar płynu, umieść klawiaturę w suchym i przewiewnym miejscu. Upewnij się, że całkowicie wyschła przed ponownym użyciem.



13



封面

型号	HL K730WGP-RGB-PRO/7341		备注：尺寸：100x100mm (折页) 材质：80g书写纸 印刷：单黑色双面印刷					
名称	说明书							
日期	2025-5-9							
页码	1 OF 1		文件编号					
绘图	雷国建	审核	香敏琪	核准		版本	A.0	