


QUICK START GUIDE

FBX51C



Bluetooth® 2.4G

FSTYLER
COLLECTION

WHAT'S IN THE BOX



Bluetooth/2.4G
Wireless Keyboard



2.4G Nano
Receiver



Type-C
Charging Cable




USB
Extension Cable



User
Manual

THE FRONT



THE FLANK / BOTTOM




CONNECTING 2.4G DEVICE




Note: USB extension cable is recommended to connect with Nano receiver.
(Make sure the keyboard is closed to the receiver within 30 cm)

CONNECTING BLUETOOTH DEVICE 1 (For Mobile Phone/Tablet/Laptop)




1: Short-press FN+7 and choose Bluetooth device 1 and light up in blue.
Long-press FN+7 for 3S and blue light flashes slowly when pairing.
2: Choose [A4 FBX51C] from your Bluetooth device.
The indicator will be solid blue for a while then light off after the keyboard is connected.

CONNECTING BLUETOOTH DEVICE 2 (For Mobile Phone/Tablet/Laptop)



1: Short-press FN+8 and choose Bluetooth device 2 and light up in green.
Long-press FN+8 for 3S and green light flashes slowly when pairing.
2: Choose [A4 FBX51C] from your Bluetooth device.
The indicator will be solid green for a while then light off after the keyboard is connected.

CONNECTING BLUETOOTH DEVICE 3 (For Mobile Phone/Tablet/Laptop)



1: Short-press FN+9 and choose Bluetooth device 3 and light up in purple.
Long-press FN+9 for 3S and purple light flashes slowly when pairing.
2: Choose [A4 FBX51C] from your Bluetooth device.
The indicator will be solid purple for a while then light off after the keyboard is connected.

OPERATING SYSTEM SWAP

Windows / Android is default system layout.

System	Shortcut [Long-Press for 3S]	Device / Layout Indicator
iOS	fn + [ios]	Light will be off after flashing.
Mac	fn + [mac]	
Windows, Chrome, Android & HarmonyOS	fn + [w/a]	

Note: The layout you used last time will be remembered. You can switch the layout by following the above step.

INDICATOR (For Mobile Phone/Tablet/Laptop)

Indicator	Yellow Light	Blue Light	Green Light	Purple Light
Multi-Device Switch	fn + [0/5]	fn + [7/3]	fn + [8/2]	fn + [9/4]
Device Switch: Short-Press for 1S	Solid Light 10S		Solid Light 5S	
Pair Device: Long-Press for 3S	No Need to Pair		Pairing: Flashes Slowly Connected: Solid Light 10S	

FN MULTIMEDIA KEY COMBINATION SWITCH

FN Mode: You can lock & unlock Fn mode by short pressing FN + ESC by turn.



- Lock Fn Mode: No need to press FN key
- Unlock Fn Mode: FN + ESC

※ After pairing, FN shortcut is locked in FN mode by default,
and the locking FN is memorized when switching and shutting down.

F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12
Home Page	System Switching	Backward	Search	Input Switching	Screen Capture	Previous Track	Play / Pause	Next Track	Mute	Volume Down	Volume Up

Windows / Android / Mac / iOS

OTHER FN SHORTCUTS SWITCH

Shortcuts	Windows	Android	Mac / iOS
fn + [delete]	Pause	Pause	Pause
fn + [↑]	Device Screen Brightness +	Device Screen Brightness +	Device Screen Brightness +
fn + [↓]	Device Screen Brightness -	Device Screen Brightness -	Device Screen Brightness -
fn + [backspace]		Screen Lock	Screen Lock (iOS Only)
fn + [enter]	Scroll Lock	Scroll Lock	


Note: The final function refer to the actual system.

DUAL-FUNCTION KEY

Multi-System Layout


Keyboard Layout	Windows / Android (W / a)	iOS / Mac (ios / mac)
fn + [ios] [mac] [w/a]	Switching Steps: ① Choose iOS layout by pressing Fn+I. ② Choose MAC layout by pressing Fn+O ③ Choose Windows / Android layout by pressing Fn+P.	
ctrl	Ctrl	Control ^
opt	Start	Option
cmd	Alt	Command
alt	Alt (Right)	Command
ctrl	Ctrl (Right)	Option

LOW BATTERY INDICATOR



USB TYPE-C RECHARGEABLE

Warning: Limite charge with 5V (Voltage)



Built-in 300mAh rechargeable lithium battery, it can be used for up to 3~5 months when fully charged.
**Battery life may vary based on user and computing conditions.

SPECIFICATIONS

Model: FBX51C
Connection: Bluetooth / 2.4G
Operating Range: 5~10 M
Multi-Devices: 4 Devices (Bluetooth x 3, 2.4G x 1)
Layout: Windows | Android | Mac | iOS
Battery: 300mAh Lithium Battery
Receiver: Nano USB Receiver
Includes: Keyboard, Nano Receiver, USB Extension Cable, Type-C Charging Cable, User Manual
System Requirements: Windows / Mac / iOS / Chrome / Android / Harmony OS...

Q & A

Question How to switch layout under different system?
Answer You can switch layout by pressing Fn + I / O / P under Windows | Android | Mac | iOS.

Question Does the layout can be remembered?
Answer The layout you used last time will be remembered.

Question How many devices can be connected?
Answer Interchange and connect up to 4 devices at the same time.

Question Does the keyboard remember the connected device?
Answer The device you connected last time will be remembered.

Question How can I know the current device is connected or not?
Answer When you turn on your device, the device indicator will be solid.
(disconnected: 5S, connected: 10S)

Question How to switch between connected Bluetooth device 1-3?
Answer By pressing FN + Bluetooth shortcut (7 - 9).

WARNING STATEMENT

The following actions may/will cause damages to the product.

- To disassemble, bump, crush, or throw into the fire, you may cause irrefutable damages in event of the lithium battery leakage.
- Do not expose under the strong sunlight.
- Please obey all local laws when discarding the batteries, if possible please recycle them. Do not dispose of it as household garbage, it may cause a fire or an explosion.
- Please try to avoid charging in the environment below 0°C.
- Do not remove or replace the battery.
- Please use the charging cable included in the package to charge the product.
- Do not use any equipment with voltage exceeding 5V for charging.

EST. 1987
A4TECH

FSTYLER
COLLECTION



www.a4tech.com



Scan for E-Manual