





SCISSOR SWITCH KEYBOARD **QUICK START GUIDE**

www.a4tech.com**Q**

FX72


Package Including

TSTYLER.

User Manual

Low Profile Scissor Switch Keyboard






COLLECTION

Low Profile Scissor Switch Keyboard

 $ig(\mathsf{Revolutionary}\ \mathsf{Anti-Ghosting}ig)$

Note: Supports Windows OS Only

Multi-key rollover ensures smooth typing and precise multi-key input, eliminating key conflicts for efficient workflows and competitive gameplay.



Emoji

www.a4tech.com

Shortcut [Long-Press for 3S]

Hide

Application

Low Profile Scissor Switch Keyboard

Function / Layout Indicator

Light will be off after flashing.

Lock

Computer



FSTYLER_

System

Mac

Windows

fn + F1 Home Page



Screenshot

Note: The layout you used last time will be remembered. You can switch the layout by following the above step. (FN Multimedia Key Combination Switch)

Volume Down

Mac

Backward Previous Track

Other FN Shortcuts Switch)

Shortcuts

Keyboard Layout

(Installation)

Software Download

TSTYLER_

Switch: Scissor Switch

(Q & A)

Answer

(Product Specifications)

Plug the USB cable to the computer USB port.

For the best product performance, please download and install the Software from www.a4tech.com/download.aspx

Note: The software does not support Mac systems.

MTECH

Connection

System Switching

Search Volume Up

www.a4tech.com

F6 Screen Capture

FSTYLER. Low Profile Scissor Switch Keyboard

Windows

Device Screen Brightness +

Device Screen Brightness -

Switching Steps:

① Choose MAC layout by pressing Fn+O.
② Choose Windows layout by pressing Fn+P.

Control ^

Option 🛰

Command 38

FSTYLER X

A Please insert KeyboardMaster-series Keyboard

RESET CANCEL APPLY

Low Profile Scissor Switch Keyboard

Report Rate: 1000 Hz

Note: The final function refer to the actual system. Dual-Function Key

Windows

Ctrl

Alt

Start 👭

CITIC 88			
alt cmd #	Alt (Right)	Command 🛎	
ctrl opt \(\subseteq \text{ctrl} \)	Ctrl (Right)	Option 🚾	
www.a4tech.com			
FSTYLER.	Low Pro	file Scissor Switch Keyboard	
COLLECTION		,	

www.a4tech.com

Character: Laser Engraving	Cable Length: 150 cm
Total Travel Distance: 2.0 mm	Port: USB
Keyboard Layout: Win / Mac	Includes: Keyboard, User Manual
Hotkeys: FN + F1 ~ F12	System Platform: Windows / Mac

Question How to switch layout under different system?

Answer The layout you used last time will be remembered.

Answer Because Mac system does not have this function.

www.a4tech.com

under Windows | Mac.

Question Does the layout can be remembered?

You can switch layout by pressing Fn + O / P

Question Why can't the function lights in Mac system prompt?



www.a4tech.com Scan for E-Manual