


QUICK START GUIDE



FSTYLER
COLLECTION

WHAT'S IN THE BOX



2.4G Numeric Keypad



Nano USB Receiver



USB Type-C Adaptor



USB Type-C Charging Cable




User Manual

KNOW YOUR NUMERIC KEYPAD


Dual Modes Num Lock

- 1 Synchronous (Default)
- 2 Asynchronous
(Press NumLock Key for 3s)




Backspace

CONNECTING 2.4G DEVICE




1

1 Plug the receiver into the computer USB port.



2

2 Use the Type-C adaptor to connect the receiver with the computer's Type-C port.




2

Turn the numeric keypad's power switch to on.

CHARGING & INDICATOR




- SOLID RED: CHARGING
- NO LIGHT: FULLY CHARGED




USB-A

USB-C



2H Charing Time


LOW BATTERY INDICATOR



Indicator

Flashing Red light indicates when the battery is below 25%.

TYPE-C RECHARGEABLE



Built-in Lithium Battery

TECH SPEC



Connection: 2.4G Hz

Operation Range: 10~15 m

Report Rate: 125 Hz

Charging Cable: 60 cm

System: Windows 7/8/8.1/10/11

Keycap: Low-Profile

Keys No.: 18

Character: Laser Engraving

Size: 87 x 124 x 24 mm

Weight: 88 g (w/ battery)

WARNING STATEMENT



The following actions may/will cause damages to the product.

1. To disassemble, bump, crush, or throwing into fire, you may cause irrefutable damages in event of the lithium battery leakage.
2. Do not expose under the strong sunlight.
3. Please obey all local laws when discarding the batteries, if possible please recycle it. Do not dispose it as household garbage, it may cause a fire or an explosion.
4. Please try to avoid charging in the environment below 0°C.
5. Do not remove or replace the battery.
6. Forbidden to use 6V to 24V charger, otherwise the product will be burned. Recommended to use a 5V charger for charging.



www.a4tech.com



Scan for E-Manual