

US UK

Dear user

Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.

1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.


O.S. Support

Windows XP/ Vista/ Win 7/ Win 8/ Win 10/ Win 11/ Mac O.S.

How to connect the keyboard with multiple devices

Wired Connection

Connect the keyboard to computer with USB cable.
The computer will recognize and configure the keyboard automatically.



Type C port

Product Features

Backlight

1. Press [FN]+[INS] to cyclic switch the default 8 backlight patterns.
2. Press [FN] + [←/→] to adjust light rotating speed, total 5 levels.
Press [FN] + [↑/↓] to adjust backlight brightness, total 5 levels.
3. Backlight color switching (available on limited light patterns): Press [FN]+[ENTER] to cycling switch Red, Green, Blue, Yellow, Purple, Cyan, White, RGB.
4. Backlight DIY: press [FN]+[BACK SPACE] to enter DIY mode, the keyboard backlight turn off, and LED indicator are flashing, press [FN]+[1~6] to set backlight color, once backlight settings are finishing, press [FN]+[BACK SPACE] to save.

Macro record

When the keyboard is not on macro mode or macro setting not settled, [G1~G4] keys value is [F1~F4] by default.

1. Press [Rec] button to start macro recording, LED indicator will flash slowly.
2. Press [G1~G4] to select a profile to record macro, LED indicator will flash quickly. Press the key you want to record into macro, K525RGB supporting max 64 keys macro recording.
3. After finishing macro key recording, press [Rec] to save the macro. If no operation over

30s during macro recording, the keyboard will save current marco setting and quit recording automatically.
To output the macro, Press [G1~G4] to output the macro.

Delete recorded macro setting:

Delete all macro setting: Press& hold [FN]+ [Rec] for 5s, LED indicator flash 1 time, all macro setting was deleted.

Delete partial macro setting: Press [Rec], LED indicator flash slowly, press the [G] key you want to delete macro, LED indicator flash quickly, Press [Rec] again, the macro setting was deleted.

[WIN] lock

Press [FN] + [WIN] to lock [WIN] key, repeat to unlock.

Shortcut keys:

Media player

Stop playing

Pre track

Play/Pause

Next track

Commands of key combinations with [FN] key

FN+F1: Media player	FN+F7: Search
FN+F2: Volume -	FN+F8: Refresh
FN+F3: Volume +	FN+F9: E-mail
FN+F4: Mute	FN+F10: Internet browser homepage
FN+F5: This PC	FN+F11: Lock keyboard
FN+F6: My favorite	FN+F12: Calculator

[W,S,A,D] and [↑, ↓, ←, →] keys switching

Press [FN] + [W] to swap the functions of the [W,S,A,D] with the [↑, ↓, ←, →] keys, repeat to recovery.

Restore factory settings

Press and hold [FN] + [ESC] for 3 seconds.


FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excessliquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.

MOUSE

Button Instructions

1. Left button
2. Right button
3. Scroll wheel
(Click as middle button)
4. Side button, defaulted forward
5. Side button, defaulted backward
6. DPI +/- (default)
7. Backlight effect switch



Quick start guide

Wired Connection

Connect the mouse to computer with USB cable.
The computer will recognize and configure the mouse automatically.

DPI adjustment and indication

Default DPI indicator color (scroll wheel LED breathing lighting)

1. RED --- 800 DPI
2. BLUE --- 1200 DPI
3. GREEN --- 1600 DPI
4. PURPLE --- 2400 DPI
5. YELLOW --- 10000 DPI

Report rate adjustment.

The mouse support adjust report rate[125Hz-250Hz-500Hz-1000Hz], use mouse software to set the report rate.

Backlight effect switching

Press the backlight button (on the bottom side of mouse) to cycling switch 8 default backlight effects.

For more adjustable function & macro recording, please download& install mouse software to enable more possibility.

FAQ

1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports.
2. If the mouse is moving slowly, jumping or with delay, please try another surface.
Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended.



FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



REDRAGON

GAMING ESSENTIALS
WIRED KEYBOARD & MOUSE BUNDLE

型号	S151(7352+4093)		备注：尺寸：100x100mm (折页) 材质：80g书写纸 印刷：单黑色双面印刷					EasternTimes Tech 	
名称	说明书								
日期	2025-3-20								
页码	1 OF 1		文件编号						
绘图	雷国建	审核	香敏琪	核准				版本	A.0