

Dear user

Thank you for you choosing **REDRAGON** Brand, to protect your rights and for better customer service, we ask that you note our warranty rules.

- 1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
- 2. Consumable parts (such as foot stick) and spare parts replacement are no included in our warranty.
- 3. Please fill out the warranty card. Warranty card is valid with the stamp of the
- 4. This warranty card will not be reissued if lost. Please keep it in a safe place.

KEYBOARD

Function Introduction


- 1. Installation: Plug & play, no need driver.
- 2. Keyboard interface: USB port, Full speed.
- 3. 25-Key roll-over: Q, A, Z, W, S, X, E, D, C, R, F, V, T, G, B, M, Space, Tab, Ctrl-L, Alt-L, Shift-L, $\uparrow\downarrow\leftarrow\rightarrow$
- 4. RGB backlighting effects:
- 1) FN+DEL, Neon mode in red, blue and green colors.
- 2) FN+INS, Spectrum mode in 7 colors.
- 3) FN+END, Enable or disable breathing mode of the backlight.
- 4) FN+HOME, static mode in one of 7 colors(red, green, blue, yellow, purple, cvan white)
- 5) FN+PGUP, static mode in one of 3 color se quence (red-blue-green, green-red -blue, blue-green-red)
- 6) FN+PGDN, ON/OFF switch mode.
- 5. Brightness adjustment:
- 1) FN+1, for brightness level +. 2) FN+J, brightness level -.
- 6. Backlighting speed adjustment:
- 1) FN+→, speed up.
- 2) FN+←, speed down
- 7. Win key lock function

FN+WIN-L() for disable WIN key and menu key. Repeat to unlock.

MOUSE

Button Instructions

- 2. Right button.
- 3. Scroll wheel (clicked as middle button).
- 4. Side button, defaulted: FORWARD
- 5. Side button, defaulted: BACKWARD
- 6. DPI+



3

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly

2. If you spill liquid on the keyboard, please remove keyboardsUSB cable from the

inserted into the corresponding USB port on the computer, or try another USB port on

computer immediately. Wipe up excess liquid and put the keyboard in a warm place

(for instance, under a lamp) to let the keyboard dry naturally before using again.

Multi-media keys

FN+F4 Mute

FN+F5 Stop

FN+F6 Pre-track

FN+F7 Play/ Pause

FN+F8 Next track

FN+F9 E-mail

FN+F10 Home

FN+F12 Search

FAO

FN+F1 Open the media player FN+F2 Volume down FN+F3 Volume up

FN+F11 Open my computer

Connect the mouse to the computer with USB cable, computer will recognize and configure the mouse automatically

DPI adjustment and indication

Default DPI indicator color (LED on the bottom) RED --- 400 DPI BLUE --- 800 DPI GREEN --- 1600 DPI PURPLE --- 2400 DPI YELLOW --- 5000 DPI

Report rates adjustment.

The mouse supports adjust report rates [125Hz-250Hz-500Hz-1000Hz], use mouse software to set the report rates.

For more adjustable function, backlight setting and macro recording, please download& install mouse software to enable more possibility.

- 1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports.
- 2. If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



REDRAGON

GAMING ESSENTIALS WIRED GAMING KEYBOARD & MOUSE BUNDLE



Wired Gaming Keyboard & mouse bundle User manual

6

封底 封面

备注:尺寸:100x100mm (折页) S107RGB-BA(7326+2881) 材质:80g书写纸 名称 说明书 印刷:单黑色双面印刷 日期 2024-12-25 页码 文件编号 1 OF 1 绘图 雷国建 审核 核准 版本 A.1

5