





US UK Dear user Thank you for choosing REDRAGON product.To protect your rights and for better customer service, please read the following warranty rules carefully. 1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included. 2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty. 1	OS Support WinXP/Vista/Win7/Win8/Win10/Win11 How to connect the keyboard with a computer   Wired Connection 1. Slide the ON/OFF switch on left side of the keyboard to OFF. 2. Take out the USB A to USB Type C cable in the package and connect the keyboard with your computer. 2	3.The computer will recognize and configure the keyboard automatically. 4.Once the keyboard is powered up, charging begins, LED of battery will turn to green when charge complete. 2.4G Wireless Connection 1. Slide the ON/OFF switch on left side of keyboard to ON. 2. Slide the 2.4G/B1/B2 switch to 2.4G. 3.press [FN2]+[ESC] for about 3 seconds, the LED marked with M flashes quickly in Blue, plug the USB receiver into any available USB port on your computer within 20 seconds. The computer will recognize and configure the keyboard automatically. Bluetooth Connection 1. Slide the ON/OFF switch on left side of keyboard to ON. 2. Slide the 2.4G/B1/B2 switch to B1 or B2. 3. Press [FN2]+[ESC], the LED marked with M flashes in Red(B1) or Green(B2) . Turn on Bluetooth and scan for available devices on your computer or smart phone. It will find "BT3.0Keyboard or BT5.0 KB" device. Select one of them to get connected with it automatically. Function Introduction 1. With standard USB and 2.4G/BT connections, the keyboard can be used on computer without any software or driver installation. 2. There are 18 backlight effects,switch by press FN2+9. 3. Commands of key combinations with [FN2] key [FN2]+[9]: Change backlight mode. There are 18 backlight effects. [FN2]+[8]: Change backlight color. [FN2] + [+]/[-]: Brightness +/-, total 6 levels. [FN2]+[0]: Turn ON/OFF the backlight. 3	[FN2]+[backspace]: Lighting record function. Press[FN2]+[backspace] to get ready recording mode, Press [FN2]+[backspace] again to start the recoding, then keep press the desired key for a favor LED color, press [FN2]+[backspace] agin to save setting. 4. Commands of key combinations with [FN1] key [FN1] + [Win]: Disable or enable the [Win] key. [FN1] + [CAPSLK]: Set the keyboard to default setting. [FN1]+[ESC]=~ [FN1]+[1]-[0]=F1~F10 [FN1]+[-, _]=F11 [FN1]+[+]=F12 [FN1]+[A]=← [FN1]+[S]=↓ [FN1]+[D]=→ [FN1]+[W]=↑ [FN1]+[P]=PRTSC [FN1]+[[]]=HOME [FN1]+[[]]=END [FN1]+[;]=PGUP [FN1]+[,>]=INSERT [FN1]+[/]=DELETE How to charge keyboard The LED indicator of battery will turn to red when keyboard is out of battery. Find the USB A to USB Type C cable in the packaging ,plug the keyboard and connect it with computer for charging. Built-in Li-thion battery 1 unit 4	FAQ 1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer. 2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use 5	BATTERY SAFETY GUIDELINES DO NOT replace the battery with a different model. DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material. If any material comes into contact with your skin or eyes. DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition. DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations. DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful. CAUTION: Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock. This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil. 6	FCC Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. 7
---	--	--	--	--	---	--

PT Prezado usuário, Obrigado por escolher a marca REDRAGON . Para proteger seus direitos e oferecer um melhor atendimento ao cliente, pedimos que você observe as regras da nossa garantia. 1. Dentro do período da garantia, os reparos são garantidos nos casos de falha devido a problemas no circuito elétrico. Danos causados pela desmontagem, por impactos violentos, imersão em água, ligação em correntes ou voltagens incorretas e danos causados por desastres naturais, como incêndios, inundações ou terremotos, não estão incluídos. 2. Peças que sofrem desgaste (como pés) e a substituição de peças avulsas não estão incluídas em nossa garantia. 8	Sistemas operacionais compatíveis WinXP/Vista/Win7/Win8/Win10 /Win11 Como conectar o teclado ao computador   Conexão com fio 1. Deslize o interruptor ON/OFF (ligado/desligado), localizado no lado esquerdo do teclado, para a posição OFF (desligado). 2. Retire o cabo USB A para tipo C da embalagem e conecte o teclado ao computador. 9	3. O computador vai reconhecer e configurar o teclado automaticamente. 4. Quando o teclado for ligado, o carregamento será iniciado. O LED da bateria acenderá na cor verde quando a carga estiver completa. Conexão sem fio 2.4 G 1. Deslize o interruptor ON/OFF (ligado/desligado), localizado no lado esquerdo do teclado, para a posição ON (ligado). 2. Deslize o botão 2.4G/B1/B2 para 2.4G. 3. Pressione [FN2]+[ESC] por cerca de três segundos. O LED marcado com M piscará rapidamente em azul. Conecte o receptor USB em qualquer porta USB disponível no computador dentro de 20 segundos. O computador vai reconhecer e configurar o teclado automaticamente. Conexão Bluetooth 1. Deslize o interruptor ON/OFF (ligado/desligado), localizado no lado esquerdo do teclado, para a posição ON (ligado). 2. Deslize o botão 2.4G/B1/B2 para B1 ou B2. 3. Pressione [FN2]+[ESC], o LED marcado com M piscará em vermelho (B1) ou verde (B2) . Ligue o Bluetooth e procure dispositivos disponíveis no computador ou no smartphone. Será encontrado o dispositivo "BT3.0Keyboard" ou "BT5.0 KB". Selecione um deles para conectar automaticamente. Apresentação da função 1. Com conexões padrão USB 2.4G/BT, o teclado poderá ser usado em computadores sem precisar instalar qualquer software ou driver. 2. Há 18 efeitos de iluminação de fundo. Para trocar, pressione FN2+9. 3. Comandos via combinações de teclas com a tecla [FN2] [FN2] + [9]: Altera a iluminação de fundo. Há dezoito efeitos de iluminação de fundo. [FN2] + [8]: Altera a iluminação de fundo. [FN2] + [+]/[-]: Intensidade +/-, total de seis níveis. [FN2] + [0]: Liga ou desliga a iluminação de fundo. 10	[FN2] + [Backspace]: Função de gravação de iluminação. Pressione [FN2]+[backspace] para preparar o modo de gravação. Pressione [FN2]+[backspace] novamente para iniciar a gravação, depois mantenha pressionada a tecla desejada para escolher a cor favorita para o LED. Pressione [FN2]+[backspace] novamente para salvar a configuração. 4. Comandos via combinações de teclas com a tecla [FN1] [FN1] + [Win]: Desativa ou ativa a tecla [Win]. [FN1] + [CAPSLK]: Aplica a configuração padrão do teclado [FN1] + [ESC]= ⇄ [FN1] + [1]-[0]= F1~F10 [FN1] + [-, _]= F11 [FN1] + [+]= F12 [FN1] + [A]= ← [FN1] + [S]= ↓ [FN1] + [D]= → [FN1] + [W]= ↑ [FN1] + [P]= PRTSC [FN1] + [+ >]= HOME [FN1] + [[]]= END [FN1] + [; >]= PGUP [FN1] + [/ >]= INSERT [FN1] + [: >]= DELETE Como carregar o teclado O LED indicador (M) da bateria ficará vermelho quando a bateria do teclado estiver descarregada. Pegue o cabo USB A para USB C na embalagem, conecte no teclado e conecte no computador para carregar. Bateria de ion de lítio embutida, 1 unidade 11	Dúvidas frequentes 1. Se o teclado não responder, verifique se o cabo USB do teclado está inserido corretamente na porta USB correspondente no computador, ou experimente outra porta USB no computador. 2. Se você derramar líquido no teclado, desconecte o cabo USB do teclado do computador imediatamente. Enxugue o excesso de líquido e coloque o teclado em um local seco e ventilado. É importante que o teclado seque naturalmente antes de utilizá-lo. 12	 REDRAGON DRACONIC PRO WIRED /2.4G /BT MECHANICAL GAMING KEYBOARD  Please scan here to download user manual  Mechanical Gaming Keyboard Operating Instructions
--	---	---	---	--	--

型号	K530RGB-PRO/8639		备注：尺寸：100x100mm (折页) 材质：80g书写纸 印刷：单黑色双面印刷				Eastertimes 1881
名称	说明书						
日期	2024-10-9						
页码	1 OF 1		文件编号				
绘图	雷国建	审核		核准		版本	A.2