



REDRAGON


FIZZ MAGNETIC+  
WIRED 60% RT MAGNETIC SWITCH  
KEYBOARD



Please scan here to  
download user manual



Gaming Keyboard User Manual



1

2

US UK

Dear user

Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.

1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.


2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

3

O.S. Support

Windows WinXP/Vista/Win7/Win8/Win10/Win11/Mac O.S.

How to connect the keyboard with device



Wired Connection

Connect the keyboard to computer with USB cable.The computer will recognize and configure the keyboard automatically.

IMPORTANT: CALIBRATE THE MAGNETIC SWITCH BEFORE  
USING THE MAGNETIC SWITCH FUNCTION!

Product Features  
Backlight

1. The default: 14 backlight patterns switch by press [FN] + [Alt\_R] to cyclic switch the light patterns. Press [FN] + [Space bar] to turn ON/OFF backlight.
2. Press [FN] + [M] to cyclic adjust backlight brightness, total 5 levels.
3. Press [FN] +[,<] to cyclic adjust light rotating speed, total 5 levels.
4. Backlight DIY: Press [FN] + [Back space] to enter DIY mode, all keys lights turn OFF, Press [FN] + [Back space] again to start recording, indicator will flash till the recording completed, Continuously press the key to select the color you want to set(except [FN]), once key light color setting are completed, press [FN] + [Back space] to save.

4

[WIN] lock

Press [FN] + [WIN] to lock [WIN] key and key, repeat to unlock.

Commands of key combinations with [FN] key

FN + [ 1 ! ]= F1	FN+[ [ { ]=Insert
FN + [ 2 @ ]= F2	FN+[ ] ]= DEL
FN + [ 3 # ]= F3	FN+[ ; : ]=Home
FN + [ 4 \$ ]= F4	FN+[ ' " ]=End
FN + [ 5 % ]= F5	FN+[ . > ]=PgUp
FN + [ 6 ^ ]= F6	FN+[ / ? ]=PgDn
FN + [ 7 & ]= F7	Fn+[ Esc ]= `
FN + [ 8 * ]= F8	Fn+[ Esc ]+[ Shift ]= ~
FN + [ 9 ( )]= F9	FN+[ A ]= ←
FN + [ 0 )]= F10	FN+[ W ]= ↑
FN + [ - _ ]= F11	FN+[ S ]= ↓
FN + [ = + ]= F12	FN+[ D ]= →

8000Hz max report rate

The keyboard supports maximum 8000Hz report rate, defaulted report rate are 1000Hz, you can adjust report rate in software.

Restore factory settings

Press and hold [FN] + [ESC] for 3 seconds.

5

For magnetic switch RT function & more adjustable function, please go to Redragon official website: [www.redragonzone.com](http://www.redragonzone.com) to download& install mouse software, to enable more possibility.

WARNING: Please keep objects with strong magnetic  
fields away from the keyboard to prevent any malfunction  
in the magnetic switch parts.

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excessliquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.



6

FCC Statement


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

7

型号	HL-K617GGB-RGB-MP/7685		备注：尺寸：100x100mm(折页) 材质：80g书写纸 印刷：单黑色双面印刷				<div>Eastertimes Tech</div> 	
名称	说明书							
日期	2025-9-26							
页码	1 OF 1		文件编号					
绘图	邓子松	审核	香敏琪		核准		版本	A.0