


Dear user

Thank you for you choosing REDRAGON Brand, to protect your rights and for better customer service, we ask that you note our warranty rules.


1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Man-made damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot stick) and spare parts replacement are not included in our warranty.

1



2

How to connect the keyboard with device



Wired Connection

Connect the keyboard to computer with USB cable. The computer will recognize and configure the keyboard automatically.

IMPORTANT: CALIBRATE THE MAGNETIC SWITCH BEFORE USING THE MAGNETIC SWITCH FUNCTION!

Product Features Backlight

1. Press [FN] + [Alt_R] to cyclic switch default 18 backlight patterns. Press [FN] + [Space bar] to turn ON/OFF backlight.
2. Press [FN] + [N] to switch the backlight color (available on limited light patterns).
3. Press [FN] + [M] to adjust backlight brightness, total 5 levels.
4. Press [FN] + [,<] to adjust light rotating speed, total 5 levels.
5. Backlight DIY: Press [FN] + [Back space] to enter DIY mode, Press [FN] + [Back space] again to start recording, [FN] key light will flash till the recording completed, Continuously press the key to select the color you want to set (except [FN] [CAPS]), once key light color setting are completed, press [FN] + [Back space] to save.

4

[WIN] lock

Press [FN] + [WIN] to lock [WIN] key and [] key, repeat to unlock.

Commands of key combinations with [FN] key

FN + [1]= F1	FN +[+]= F12
FN + [2@]= F2	FN+[[[=Insert
FN + [3#]= F3	FN+[]]= DEL
FN + [4\$]= F4	FN+[:]=Home
FN + [5%]= F5	FN+["]=End
FN + [6^]= F6	FN+[,]=PgUp
FN + [7&]= F7	FN+[/]=PgDn
FN + [8*]= F8	FN+[A]= ←
FN + [9(]= F9	FN+[D]= →
FN + [0)= F10	FN+[W]= ↑
FN +[-_]= F11	FN+[S]= ↓

Restore factory settings

Press and hold [FN] + [CAPS] for 3 seconds.

CAPS indicator

When ON, the [CapsLk] key steadily lights on white, and when OFF, it follows the lighting effect of the keyboard.

5

For magnetic switch RT function, DKS & more adjustable function, please go to Redragon official website/ web-driver website: <http://www.redragonzone.com/> <http://launcher.redragonzone.com> to connect to web-driver, enable more possibility of your Redragon keyboard.

WARNING: Please keep objects with strong magnetic fields away from the keyboard to prevent any malfunction in the magnetic switch parts.

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.
2. If you spill liquid on the keyboard, please remove keyboardsUSB cable from the computer immediately. Wipe up excess liquid and put the keyboard in a warm place (for instance, under a lamp) to let the keyboard dry naturally before using again.



6

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

1. **Cleaning Instructions:** Before cleaning, always unplug the device from the computer's USB port. Clean the surfaces with a soft, dry cloth. For stubborn dirt, use a cloth that is slightly dampened with water. Do not use chemical agents or solvents. Ensure the devices are completely dry before reconnecting them.
2. **Ergonomic Health and Safety Guide:** Incorrect or prolonged use of computer equipment can lead to discomfort, fatigue, headaches and serious long-term injuries known as musculoskeletal disorders (MSDs). Please take relaxation breaks every 30-60 minutes.
3. **WARNING:** The product is not a toy. Please keep it out of reach of small children. The product contains small components that may pose a choking hazard.

7



REDRAGON

VENOM

WIRED RT MAGNETIC SWITCH KEYBOARD



Gaming Keyboard User Manual