

封面

封底



US UK Dear user Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules. 1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included. 2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty.	Button Instructions 1. Left mouse button. 2. Right mouse button. 3. Scroll wheel (clicked as middle mouse button). 4. Side key, defaulted forward. 5. Side key, defaulted backward. 6. DPI button. 7. Power button: 2.4G/OFF/BT button. 8. Teflon foot pads: Large wear-resistant materials let the mouse move more smoothly. 1 2 3 4 5 6 7 8	Basic Operation: How to Connect the Mouse with a Computer 1. Take out the USB to USB C cable in the package and connect the mouse with your computer. 2. Slide the power switch on the bottom of the mouse at any mode(2.4G/OFF/BT). The mouse is under recharging. 3. The computer will recognize and configure the mouse automatically at wired mode. 4. The mouse will be ready for use when the configuration is finished. 2.4G wireless pairing 1. Slide the power switch on bottom of the mouse to 2.4G. 2. Take out the USB receiver in the package and plug it into any available USB port on your computer. 3. Press any button on mouse, the computer will recognize and configure the keyboard automatically. BT pairing 1. Slide the power switch on bottom of the mouse to BT. 2. Press button 1 + 6 and hold for 3 seconds, switch on PC or tablet BT, search the mouse as BT5.1 mouse, press it for pairing. BT OFF 2.4G	Auto sleep and power save function The gaming mouse will be sleep mode if it is out of work in 1 minutes, please move the mouse or press any key to wake it up. How to Recharge the Battery 1. The scroll wheel light will flash in red when battery is low, you need to recharge the mouse now. 2. Take out the USB to USB C cable and connect the mouse and any USB power output port. 3. Charging time is around 4 hours. 4. Note: Slide the power switch on the bottom of the mouse to OFF for long term storage. CAUTION: DO NOT CHARGE THE MOUSE BY WALL PLUG, INPUT VOLTAGE MAX 7V. DPI adjustment and indication DPI indicator light: Behind the Scroll Wheel key, there is a DPI indicator light. Red ----- Gear 1 (1000 DPI) Blue ----- Gear 2 (2000 DPI) Green ----- Gear 3 (4000 DPI) Purple ----- Gear 4 (8000 DPI) Yellow ----- Gear 5 (26000 DPI)	Built-in Li-thion battery 1 unit. FAQ 1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports. 2. If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended. REDRAGON QUALITY ASSURED	FCC Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device complies with Part 15 of the FCC Rules and contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation
BATTERY SAFETY GUIDELINES DO NOT replace the battery with a different model. DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material. DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes. DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition. DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations. DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful. CAUTION Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock. Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil. This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.	PL Drugi Użytkownika Dziękujemy za wybranie marki REDRAGON. Aby chronić swoje prawa i korzystać z lepszej obsługi klienta, zwróć uwagę na nasze warunki gwarancji. 1. W okresie gwarancji naprawa jest objęta gwarancją w przypadku awarii spowodowanej problemami z obwodami elektrycznymi. Nie uwzględnia się szkód spowodowanych przez człowieka, takich jak demontaż, silne uderzenia, zanurzenie w wodzie, podłączanie do niewłaściwego prądu lub napięcia ani szkód spowodowanych przez kłeski żywiołowe, takie jak pożar, powódź lub trzęsienie ziemi. 2. Części eksploatacyjne (np. stopka) oraz części zamienne nie są objęte naszą gwarancją 1 2 3 4 5 6 7 8	Instrukcje dotyczące przycisków 1. Lewy przycisk myszy. 2. Prawy przycisk myszy. 3. Kółko przewijania (kliknięcie środkowym przyciskiem myszy). 4. Przycisk boczny, domyślnie do przodu. 5. Przycisk boczny, domyślnie do wstecz. 6. Przycisk DPI. 7. Przycisk zasilania: przycisk 2.4G/WYŁ./BT. 8. Stopki teflonowe: Duże, odporne na ścieranie materiały sprawiają, że mysz porusza się płynnie. 1 2 3 4 5 6 7 8	Podstawowa obsługa: Jak podłączyć mysz do komputera 1. Wyjmij kabel USB na USB C znajdujący się w opakowaniu i podłącz mysz do komputera. 2. Przesuń przełącznik zasilania na spodzie myszy w dowolny tryb 2.4G/OFF/BT. Mysz jest w trakcie ładowania. 3. Komputer automatycznie rozpozna i skonfiguruje mysz w trybie przewodowym. 4. Mysz będzie gotowa do użycia po zakończeniu konfiguracji. Parowanie bezprzewodowe 2.4G 1. Przesuń przełącznik zasilania na spodzie myszy na 2.4G. 2. Wyjmij odbiornik USB z opakowania i podłącz go do dowolnego dostępnego portu USB w komputerze. Pamiętaj 3. Naciśnij dowolny przycisk na myszy, komputer automatycznie rozpozna i skonfiguruje mysz. Parowanie BT 1. Przesuń przełącznik zasilania na spodzie myszy na BT. 2. Naciśnij przyciski 1 + 6 i przytrzymaj przez 3 sekundy, włącz BT w komputerze lub tablecie, wyszukaj mysz jako mysz BT5.1, naciśnij ją, aby sparować. BT Wył. 2,4 G	Funkcja automatycznego uśpienia i oszczędzania energii Mysz do gier będzie w trybie uśpienia po upływie 1 minuty bezczynności, porusz myszą lub naciśnij dowolny przycisk, aby ją obudzić. Jak naładować baterię? 1. Gdy bateria jest na wyczerpaniu, podświetlenie kółka przewijania będzie migać na czerwono, należy naładować mysz. 2. Wyjmij kabel USB do USB C i podłącz mysz do dowolnego portu USB. 3. Czas ładowania wynosi około 4 godzin. 4. Uwaga: Przesuń przełącznik zasilania na spodzie myszy do pozycji OFF (WYŁ.) na czas dłuższego przechowywania. OSTROŻNIE : NIE NALEŻY ŁADOWAĆ MYSZY Z GNIAZDKA ŚCIENNEGO, MAKS. NAPIĘCIE WEJŚCIOWE 7V. Regulacja i wskazanie DPI Wskaźnik świetlny DPI za kółkiem przewijania dostępny jest wskaźnik świetlny DPI. Czerwony ----- Bieg 1(1000 DPI) Niebieski ----- Bieg 2(2000 DPI) Zielony ----- Bieg 3(4000 DPI) Fioletowy ----- Bieg 4(8000 DPI) Złoty ----- Bieg 5(26000 DPI) Wbudowana bateria litowo-jonowa – 1 sztuka.	Często zadawane pytania 1. Jeżeli mysz nie reaguje, sprawdź, czy jest podłączona prawidłowo do odpowiedniego złącza USB w komputerze lub wypróbuj inne złącze USB. 2. Jeśli kursor porusza się powoli, skokowo lub w sposób przerywany, spróbuj innej powierzchni. Powierzchnie ciemne, zabrudzone, nieplaskie lub jasne mogą mieć wpływ na działanie myszy. Zaleca się użycie podkładki pod mysz.

型号	红龙M916-PRO-1K 2986		备注： 尺寸： L100*W100mm 材质： 80g书写纸， 风琴折页， 正反印 印刷： 单色				
名称	说明书(英+波兰)						
日期	2024-12-16						
页码	1 OF 1		文件编号				
绘图	吴九香	审核		核准		版本	A.0