



REDRAGON

K1NG 4K PRO

WIRELESS ULTRA LIGHT-WEIGHT 4K E-SPORT GRADE GAMING MOUSE



Please scan here to download user manual



Wireless Ultra Light-weight 4K E-sport Grade Gaming Mouse Operating Instructios

US UK

Dear user

Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules.

1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.

2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty.

Button Instructions

1. Left mouse button.

2. Right mouse button.

3. Scroll wheel (clicked as middle mouse button).


4. Side key, defaulted forward.

5. Side key, defaulted backward.

6. DPI button.

7. Power button:BT/OFF/2.4G switch button.

8. Teflon foot pads: Large wear-resistant materials let the mouse move more smoothly.



1

Basic Operation:

How to Connect the Mouse with a Computer

1. Take out the USB to USB C cable in the package and connect the mouse with your computer.

2. Slide the power switch on the bottom of the mouse at any mode(2.4G/OFF/BT), The mouse is under recharging.

3. The computer will recognize and configure the mouse automatically at wired mode.

4. The mouse will be ready for use when the configuration is finished.

2.4G wireless pairing

1. Slide the power switch on bottom of the mouse to 2.4G.

2. Take out the USB receiver in the package and plug it into any available USB port on your computer, please note that the USB receiver can be storage on the bottom of mouse.

3. Press any button on mouse, the computer will recognize and configure the keyboard automatically.

BT pairing

1. Slide the power switch on bottom of the mouse to BT.

2. Press button ➊ + ➋ and hold for 3 seconds, switch on PC or tablet BT, search the mouse as BT5.1 mouse, press it for pairing.



BT
OFF
2.4G

2

Auto sleep and power save function

The gaming mouse will be sleep mode if it is out of work in 1 minutes, please move the mouse or press any key to wake it up.

How to Recharge the Battery

1. The scroll wheel light will flash in red when battery is low, you need to recharge the mouse now.

2. Take out the USB to USB C cable and connect the mouse and any USB power output port.

3. Charging time is around 4 hours.

4. Note: Slide the power switch on the bottom of the mouse to OFF for long term storage.

CAUTION:

DO NOT CHARGE THE MOUSE BY WALL PLUG, INPUT VOLTAGE MAX 7V.

DO NOT PLUG USB CABLE OR 2.4G DONGLE VIA USB HUB UNDER 4K OR 8K REPORT RATE.

DPI adjustment and indication

DPI indicator light: Behind the Scroll Wheel key, there is a DPI indicator light.

Red ----- Gear 1 (500 DPI)

Blue ----- Gear 2 (1000 DPI)

Green ----- Gear 3 (2000 DPI)

Purple ---- Gear 4 (4000 DPI)

Yellow ---- Gear 5 (8000 DPI)

Report rate adjustment

125Hz/250Hz/500Hz/1000Hz/2000Hz/4000Hz, the report rate is avaiable to adjust in software(Not available at BT mode).

3

Software Instructions

User can adjust the following settings through the software after downloading and installing it.

1. Adjust the DPI of the mouse at the user's discretion.

2. Adjust the polling rate of the mouse at the user's discretion.

3. Macros: Record up to 59 actions and trigger with one key.

4. Continuous keystroke function: Set the number of clicks and delay time.

5. Customize buttons' function.

FAQ

1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports.

2. If the mouse is moving slowly, jumping or with delay, please try another surface.

Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended.

4

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Part 15 of the FCC Rules and contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation

5

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.

DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.

DO NOT touch the battery fi material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.

DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.

DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.

DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.

CAUTION

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

6

PT

Prezado usuário,

Obrigado por escolher a marca REDRAGON . Para proteger seus direitos e oferecer um melhor atendimento ao cliente, pedimos que você observe as regras da nossa garantia.

1. Dentro do período da garantia, os reparos são garantidos nos casos de falha devido a problemas no circuito elétrico. Danos causados pela desmontagem, por impactos violentos, imersão em água, ligação em correntes ou voltagens incorretas e danos causados por desastres naturais, como incêndios, inundações ou terremotos, não estão incluídos.

2. Peças que sofrem desgaste (como pés) e a substituição de peças avulsas não estão incluídas em nossa garantia.

7

Instruções dos botões

1. Botão esquerdo do mouse.

2. Botão direito do mouse.

3. Botão da rodinha (clicado como botão do meio do mouse).


4. Tecla lateral, avança por padrão.

5. Tecla lateral, volta por padrão.

6. Botão DPI.

7. Botão de energia: botão alterna entre BT/DESL/2.4G.

8. Pés de teflon: Materiais grandes e resistentes ao desgaste permitem movimentos mais suaves do mouse.



8

Operação básica:

Como conectar o mouse a um computador

1. Retire o cabo USB C da embalagem e conecte o mouse ao computador.

2. Deslize o botão de energia na parte inferior do mouse em qualquer um dos modos (2.4G/OFF/BT). O mouse começará a ser carregado .

3. O computador vai reconhecer e configurar o mouse automaticamente no modo com fio.

4. O mouse estará pronto para uso quando a configuração estiver concluída.

Pareamento com 2.4G

1. Deslize a chave na parte inferior do mouse para a posição 2.4G

2. Retire o receptor USB da embalagem e conecte em uma porta USB disponível no computador. Observe que o receptor USB pode estar armazenado na parte inferior do mouse.

3. Pressione qualquer botão do mouse, o computador vai reconhecer e configurar o teclado automaticamente.

Pareamento BT

1. Deslize a chave na parte inferior do mouse para a posição BT.

2. Pressione o botão ➊ + ➋ por 3 segundos, ligue o BT do PC ou do tablet, procure o mouse como BT5.1 e pressione para parear.



BT
OFF
2.4G

9

Função de desativação automática para economia de energia

O mouse para jogos entrará no modo inativo se ficar sem uso por mais de 1 minutos. Mova o mouse ou pressione qualquer tecla para reativá-lo.

Como recarregar a bateria

1. A luz da roda de rolagem piscará em vermelho quando a bateria estiver fraca e for necessário recarregar a bateria.

2. Retire o cabo USB para USB C e conecte o mouse a qualquer porta USB.

3. O tempo de carregamento é de 4 horas.

4. Observação: Deslize o interruptor de energia na parte inferior do mouse estiver para a posição OFF (desligado) para armazenamento por longos períodos.

CUIDADO: NÃO CARREGUE O MOUSE LIGANDO O PLUGUE NA TOMADA DA PAREDE. VOLTAGEM MÁXIMA 7 V.

Ajuste e indicação de DPI

Indicador luminoso de DPI: atrás da rodinha de rolamento, há um indicador luminoso de DPI.

Vermelho --- Velocidade 1 (500 DPI)

Azul ----- Velocidade 2 (1000 DPI)

Verde ----- Velocidade 3 (2000 DPI)

Roxo ----- Velocidade 4 (4000 DPI)

Amarelo ---- Velocidade 5 (8000 DPI)

10

Instruções do software

O usuário pode fazer os seguintes ajustes por meio de software, após baixar e instalar.

1. Ajustar o DPI do mouse pelo usuário.

2. Ajuste da velocidade de leitura do mouse pelo usuário.

3. Macros: Grave até 59 ações e dispare com uma tecla.

4. Função de pressionamento constante: defina o número de cliques e a duração do intervalo.

5. Personalizar funções dos botões.

Dúvidas frequentes

1. Se o mouse não estiver respondendo, verifique se o mouse está conectado corretamente na porta USB correspondente do computador ou experimente usar outra porta USB.

2. Se o cursor estiver se movimentando lentamente, saltando ou com movimentos intermitentes, experimente outra superfície. Superfícies escuras, sujas, irregulares ou brilhantes podem afetar o desempenho do mouse. É recomendado o uso de um mouse pad.



11

型号	红龙M916-PRO-4K 4076	备注:	尺寸: L100*W100mm
名称	说明书(英+巴西)		材质: 80g书写纸, 风琴折页, 正反印
日期	2025-5-22		印刷: 单色
页码	1 OF 1	文件编号	
绘图	吴九香	审核	香敏琪
		核准	
			版本
			A.1

Eastemtimes
Tech

ET