REDRAGON

EBONY ULTRA

3-MODE WIRELESS GAMING MOUSE
& CHARGING DOCK

Please scan here to download operating instructions

3-Mode Wireless Gaming Mouse & Charging Dock Operating Instructions

US UK

Dear user

Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules.

1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty.

Button Instructions

1. Left button
2. Right button
3. Scroll wheel(Click as middle button)
4. Side button, defaulted forward
5. Side button, defaulted backward
6. DPI button
7. BT pair button
8. Mode/Power switch: BT Mode/OFF(Power off) /2.4G Mode
9. Charging dock light effect switch
10. Screen display content switch



Wired Connection

Connect the mouse to computer with USB cable in ANY mode, the mouse will turn to WIRED connection, The computer will recognize and configure the mouse automatically, and charging the mouse at the same time.

2.4G Wireless Connection

1. Connect the computer and charging dock with a USB Type-c cable.
2. [BT/OFF/2.4G] switch on "2.4G", the mouse will connect automatically.

BT Connection

[BT/OFF/2.4G] switch on "BT", the indicator is blue light quickly flashes, press ⑦ button for 3s to pairing. Turn on the computer BT and search for available device, and select device name " BT 5.3 Mouse", the computer will recognize and configure the mouse automatically.

DPI adjustment and indication

Press ⑥button to cyclic switch DPI in 400 DPI/800 DPI/1600 DPI/2400 DPI/3200 DPI, when adjusting DPI, the DPI indicator flashes as below:
RED -------- 400 DPI
BLUE------- 800 DPI
GREEN ---- 1600 DPI
CYAN ------ 2400 DPI
PURPLE --- 3200 DPI
The mouse support max 30000 DPI, download & install the software to adjusting.

Report rate adjustment and indication

Press ③~④buttons to cyclic adjust report rate in 125Hz/250Hz/500Hz/1000 Hz/2000Hz/4000Hz/8000Hz, when adjusting report rate, the LED indicator will flash in White as below:

Report rate	LED twinkle times
125Hz	1
250Hz	2
500Hz	3
1000Hz	4
2000Hz	5
4000Hz	6
8000Hz	7

(Report rate adjustment is not available on BT mode.)

Charging dock

Light effect switching: press ⑨ button to cyclic switch 8 light effects.
Screen content switching: press ⑩ button to cyclic switch display contents: DPI/MRR(mouse report rate)/LOD/gif.
Auto sleep and power save function
The mouse will enter sleep mode when it is out of operation in 3 minutes, move or click any button to wake it up. If you do not use it for a long time, please turn the bottom switch to OFF to save energy.

How to recharge

1. Low battery warning---the DPI indicator light will flash red when the battery is low.
2. Charging:
   1)Connect the charging dock to the computer with a USB Type-C cable, [BT/OFF/2.4G] switch on "2.4G", place the mouse on the charging dockto recharge the mouse.
   2)Connect the mouse to the computer or an AC adapter to recharge the mouse.

⚠ Warning:Charging current: 5V ⎓ 1A max.

DO NOT use fast-charging adapter to recharge your mouse!

Built-in Li-thion battery 1 unit.

FAQ

1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports.
2. If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.
DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.
DO NOT touch the battery fi material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.
DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.
DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.
DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.

⚠ CAUTION

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

PT

Prezado usuário,

Obrigado por escolher a marca REDRAGON . Para proteger seus direitos e oferecer um melhor atendimento ao cliente, pedimos que você observe as regras da nossa garantia.

1. Dentro do período da garantia, os reparos são garantidos nos casos de falha devido a problemas no circuito elétrico. Danos causados pela desmontagem, por impactos violentos, imersão em água, ligação em correntes ou voltagens incorretas e danos causados por desastres naturais, como incêndios, inundações ou terremotos, não estão incluídos.
2. Peças que sofrem desgaste (como pés) e a substituição de peças avulsas não estão incluídas em nossa garantia.

Instruções dos botões

1. Botão esquerdo
2. Botão direito
3. Botão da roda (clicado como botão do meio)
4. Botão lateral, avança por padrão
5. Botão lateral, volta por padrão
6. Botão DPI -
7. Botão de pareamento do BT
8. Chave de modo/energia:Modo Bluetooth/OFF (Desligado)/Modo 2.4G
9. Alternância do efeito de luz da base de carregamento
10. Alternância do conteúdo exibido na tela

Conexão com fio

Conecte o mouse ao computador com o cabo USB em qualquer modo; o mouse passará para o modo COM FIO.
O computador reconhecerá e configurará o mouse automaticamente e o dispositivo será carregado ao mesmo tempo.

Conexão sem fio 2.4 G

1. Conecte o computador e a base de carregamento com um cabo USB Type-C.
2. Coloque a chave [BT/OFF/2.4G] na posição "2.4G"; o mouse se conectará automaticamente.

Conexão com BT

Coloque a chave [BT/OFF/2.4G] na posição "BT"; o indicador piscará rapidamente em azul.
Pressione o botão ⑦ por 3 segundos para iniciar o pareamento.Ative o Bluetooth do computador e procure os dispositivos disponíveis.
Selecione o dispositivo com o nome "BT 5.3 Mouse"; o computador reconhecerá e configurará o mouse automaticamente.

Ajuste e indicação de DPI

Pressione o botão ⑥para alternar entre os valores de DPI entre 400DPI/800DPI/1600DPI/2400DPI/3200 DPI, quando ajustar o DPI, o indicador de DPI piscará conforme indicado abaixo:
VERMELHO --- 400 DPI
AZUL ---------- 800 DPI
VERDE --------- 1600 DPI
CIANO --------- 2400 DPI
ROXO --------- 3200 DPI
O mouse é compatível com até 30000DPI. Baixe e instale o software para fazer os ajustes.

Ajuste e indicação da velocidade de leitura

Pressione as teclas ③ + ④ para alternar a taxa de resposta entre 125 Hz, 250 Hz, 500 Hz, 1000 Hz, 2000 Hz e 4000 Hz. Durante o ajuste da taxa de resposta, o LED indicador piscará em branco conforme mostrado abaixo:

Taxa de leitura	O LED pisca
125Hz	1vez
250Hz	2vez
500Hz	3vez
1000Hz	4vez
2000Hz	5vez
4000Hz	6vez
8000Hz	7vez

(O ajuste da velocidade de leitura não está disponível modo BT.)

Base de carregamento

Para alternar o efeito de iluminação: pressione o botão ⑨ para alternar entre 8 efeitos de iluminação.
Alternância do conteúdo da tela: pressione o botão ⑩ para alternar entre os conteúdos exibidos:DPI/MRR (taxa de resposta do mouse)/LOD/gif.

Função de desativação automática para economia de energia

O mouse entrará em modo de suspensão após 3 minutos de inatividade.
Mova-o ou pressione qualquer botão para reativá-lo.Se não for utilizá-lo por um longo período, coloque a chave inferior na posição OFF para economizar energia.

Como configurar

1. Aviso de bateria fraca — o indicador de DPI piscará em vermelho quando a bateria estiver com pouca carga.
2. Carregando:
   1)Conecte a base de carregamento ao computador com um cabo USB Type-C; coloque a chave [BT/OFF/2.4G] na posição "2.4G"; posicione o mouse sobre a base para recarregá-lo.
   2)Conecte o mouse ao computador ou a um adaptador de energia para recarregar bateria.

Bateria interna de íon de lítio, 1 unidade.
NÃO use adaptador de carregamento rápido para recarregar o mouse!

⚠ Aviso: Corrente de carga: 5V ⎓ 1A max

Dúvidas frequentes

1. Se o mouse não estiver respondendo, verifique se o mouse está conectado corretamente na porta USB correspondente do computador ou experimente usar outra porta USB.
2. Se o cursor estiver se movimentando lentamente, saltando ou com movimentos intermitentes, experimente outra superfície. Superfícies escuras, sujas, irregulares ou brilhantes podem afetar o desempenho do mouse. É recomendado o uso de um mouse pad.

型号	红龙M998-ULT 4108+4111	备注：	尺寸：L100*W100mm 材质：80g书写纸，风琴折页，正反印 印刷：单色				Easternimes Tech
名称	说明书(英+巴西)						
日期	2025-10-31						
页码	1 OF 1	文件编号					
绘图	曾超余	审核	香敏琪	核准		版本	A.0